


GS4 / GS5 Heat Pump Parts list



GS4-45HPC



GS4 / GS5 Spare Parts



Model #: GS4-45HPC, GS4-45HPC-D, GS5-45HPC, GS5-45HPC-D

No.	Part name	Notes		GS4 Heat Pump	GS5 Heat Pump
1	Front Panel	Includes fan guard / shroud		GS4-969704	
2	Top Panel			GS4-887542	
3	Right Side Panel			GS4-969705	
4	Left Side Panel			GS4-937002	
5	Piping Cover			GS4-969711	
6	Fan Guard			GS4-887545	
7	Main PCB			GS4-969712	GS5-969797
8	Control PCB			GS4-969714	GS5-969798
10	Display PCB Assembly			GS4-887552	
11	Sensor (Temp. Outdoor)			GS4-883780	
12	Sensor (Temp. Discharge)	Black	Pair	GS4-938629	
13	Sensor (Temp. Suction)	White			
14	Sensor (Temp. Defrost)			GS4-938630	
15	Sensor (Temp. Water Outlet)	Black	Pair	GS4-938631	
16	Sensor (Temp. Water Inlet)	White			
17	Reactor			GS4-938635	
18	Pump (+ Pump Air Bleed Drain Plug)			GS4-969727	
20	Pump Clip			GS4-944732	
21	Fan Motor			GS4-943587	
22	Propeller Fan			GS4-938641	
23	Fan Holder Nut			GS4-808329	
24	Water Air Bleed Plug (+ O-RING)			GS4-925935	
25	O Ring (P3)			GS4-925918	
26	O Ring (P14)			GS4-761943	
28	Conduit Clip			GS4-887566	
29	Drain Elbow			GS4-881618	

* Please call your seller / distributor for pricing and availability.

** GS4 and GS5 parts are interchangeable with the exception of Main PCB and Control PCB. While GS4 PCBs CANNOT be used for GS5 Heat Pump, GS5 PCBs can be used as replacement parts for GS4 Heat Pump.